

# Hanging Instructions

Strata - Porcelain

## CAUTION

Inspect all panels for defects in construction prior to cutting or installing the wallcovering. Returns will not be accepted on cut panels. The fractures within the panels are completely random and there will be no side match. Each panel is notated with the recommended sequential and directional placement necessary for a successful installation.

## INSTALLATION

- Only professional wallpaper hangers should be contracted to install our wallcoverings.
- Walls must be properly sealed with a wallpaper primer.
- A very light misting of water on the back of the wallcovering is suggested to enable easier trimming of the product. Several passes with a new razor blade may be required to complete the trimming process.
- Care should be taken in handling the wallcovering to avoid creasing or tightly folding it so additional fractures are not created.
- A clay based adhesive is recommended for installation. An appropriate amount of adhesive should be applied to the wallcovering as well as a thin layer to the wall. The adhesive that is applied to the wall should be allowed to tack-up prior to hanging the wallcovering and the adhesive applied to the wallcovering should be allowed to relax to make the wallcovering more pliable.
- The surface of the wallcovering can scratch if tools are directly applied during hanging and smoothing; it is suggested that the paper liner that accompanies the wallcovering on the roll be utilized as a buffer between the wallcovering and tools to prevent damage to the surface of the wallcovering.
- This wallcovering is not covered under a warranty and no guarantee is offered against color fading, shrinkage, damage, or change due to contact with any liquid or substance.



*If you have any questions, please feel free to call us directly.*

# Touch-Up Instructions

Strata - Porcelain

- Shake touch-up solution prior to use.
- It is important to apply the solution only to the area that requires repair; if it is applied to an area that is the proper color it will darken that area and become noticeable.
- When blotting during the repair it is important not to apply too much pressure as you could spread the solution to an area that does not require touch-up and darken that area.
- For small round touch-ups use the brush provided and apply a small amount of the solution to the area requiring repair. Lightly blot the area with a clean cloth and repeat as necessary.
- For lines that need repair use the brush as a pencil and lightly draw a thin line in the touch up area only. Lightly blot the area and repeat as necessary.
- For larger areas lightly add color to the center of the site to be touched up and slowly work outwards, never touching the original color. Lightly blot the area and repeat as necessary.

*If you have any questions, please feel free to call us directly.*

