



BRODERICK

CAUTION

Inspect product for major defects in construction prior to cutting or installing. When unpacking the wallcovering you may notice it does not lay flat. DO NOT BACK ROLL, as it will relax once misted and pasted. Back rolling may cause stressing of the wood veneer. Returns will not be accepted on cut rolls.

PROFESSIONAL HANGERS

Only professional wallpaper hangers should be contracted to install Gregorius Pineo wallcoverings. Our wallcoverings are not covered under a warranty and no guarantee is offered against color fading, shrinkage, damage, or change due to contact with any liquid.

IF YOU HAVE ANY QUESTIONS
PLEASE FEEL FREE TO CALL US DIRECTLY.

ADHESIVES

We suggest using a clear, non-staining, vinyl adhesive when installing our wallcoverings. Do not dilute the adhesive. Wall surfaces must be properly prepared prior to application. To remove excess adhesive from the surface, use a clean moist sponge and blot area of contact. Dry surface with a lint free towel. Do not scrub or rub.

TRIMMING

Our wallcoverings have not been pre-trimmed, and trimming is required. **Trim .25 inch off each side of the width. Failure to trim accordingly will result in the pattern not matching.**

INSTALLATION

Adhesive should be applied to the wall and not the wallcovering, it is recommended to lightly mist the back of the wallcovering with water, let it dry and mist again prior to installation. This will prevent any shrinkage, or bubbles from forming after the wallcovering is adhered to the wall.